





Комплект универсальных чернил Hi-Black 4 цвета (Вк, С, М, Y) для Epson (Тип Е), на водной основе

 **Тип чернил:**
водорастворимые

 **Количество цветов:** 4

 **Тип печати:**
струйная

 **Комплектация:** 4 цвета чернил,
черный (black) — 100 мл., пурпурный (magenta) — 100 мл.
голубой (cyan) — 100 мл., жёлтый (yellow) — 100 мл.

Универсальные чернила для струйных печатающих устройств Epson (принтер, мфу), кроме профессионального оборудования (плоттеров).

Совместимость:

Epson Stylus Photo P50

Epson Stylus Photo R270, Epson Stylus Photo R290, Epson Stylus Photo R295

Epson RX420, Epson RX520, Epson Stylus Photo RX500, Epson Stylus Photo RX610

Epson Stylus SX130, Epson Stylus SX125, Epson Stylus S22, Epson Stylus SX230,
Epson Stylus SX235W, Epson Stylus SX430W, Epson Stylus SX438W, Epson Stylus SX420W,
Epson Stylus SX425W, Epson Stylus SX435W, Epson Stylus SX440, Epson Stylus SX440W,
Epson Stylus SX445W

Epson Stylus C63, Epson Stylus C65

Epson Stylus CX3900, Epson Stylus CX4900, Epson Stylus CX7300, Epson Stylus CX8300,
Epson Stylus CX5900, Epson Stylus CX9300, Epson Stylus CX6900F

Epson Expression Home XP-103, Epson Expression Home XP-203,
Epson Expression Home XP-207, Epson Expression Home XP-235,
Epson Expression Home XP-245, Epson Expression Home XP-247,
Epson Expression Home XP-303, Epson Expression Home XP-306,
Epson Home XP-303, Epson Expression Home XP-600, Epson Expression Home XP-800,
Epson Expression Home XP-313, Epson Expression Home XP-323,
Epson Expression Home XP-332, Epson Expression Home XP-335,
Epson Expression Home XP-342, Epson Expression Home XP-345,
Epson Expression Home XP-403, Epson Expression Home XP-406,
Epson Expression Home XP-413, Epson Expression Home XP-423,
Epson Expression Home XP-435



Рекомендации:

После вскрытия флакона, чернила использовать в течение 5-ти месяцев при соблюдении условий хранения.



Подробная
инструкция